



Fasteners Through the Web Areas

## General Notes:

- 1. Fastener spacing and end distance is 3/4" (19mm) minimum, except as shown.
- 2. Refer to approved truss drawings for required fastener type and quantities for each fastener contact area.
- 3. Fastener contact areas that coincide with other contact areas may use a common fastener for both areas. This will result in a reduction in the total number of fasteners required at the pitch break joint.
- 4. Lengths "L" are equal.
- = Fastener contact area.



www.TrusSteel.com

Connector Fastener Area

Alpine, a division of ITW Building Components Group, Inc. shall not be responsible for any performance failure in a connection due to a deviation from this detail. Any variation from this detail shall be approved in advance by Alpine, a division of ITW Building Components Group, Inc.

Standard Detail:

TS004B

Date:

06/01/22

TrusSteel Detail Category:

Pitch Break Connections

155 Harlem Ave., North Building, 4th Floor / Glenview, IL 60025 / (800) 755-6001